



www.rodexit.com

**STRAIGHT Proofing Strip Installation Guide**  
**Sectional and Single Panel Up and Over Garage Doors**  
**Installation by Means of a Mounting Strip**  
**April 2021**


**CONTENTS**

1	IMPORTANT INTRODUCTION	2
1.1	The Garage Doors	2
1.2	Installation With or Without a Mounting Strip	2
1.3	Do Not Press the Proofing Strip Hard Against the Threshold and the Side Jamb	2
1.4	Bottom Weather Seals	3
1.5	Mounting Strips	3
1.6	Monitoring and Maintenance	4
2	PROOFING WOODEN GARAGE DOORS	4
2.1	Tools and Materials	4
2.2	Proofing the Threshold Gap	6
2.3	Proofing the Side Gaps	12
2.3.1	Installation of the STRAIGHT Proofing Strip	12
2.3.2	Single Panel Canopy Doors	13
2.3.3	Sectional Doors	13
2.3.4	Single Panel Retractable Doors	13
2.3.5	Rodent Proofing Stop Molding Side Seals	14
3	PROOFING METAL GARAGE DOORS	14
3.1	Tools and Materials	14
3.2	Proofing the Threshold Gap and the Side Gaps	15
4	TIPS & TRICKS	16
4.1	If a Very High Degree of Protection is Required	16
4.2	How to Handle Very Uneven Thresholds	17
4.3	Why Are Tin Snips with Long Blades Best?	18
4.4	A Very Useful Homemade Tool	18

# 1 IMPORTANT INTRODUCTION

## 1.1 The Garage Doors

This is a guide on the rodent proofing of sectional and single panel up and over garage doors with the rodent resistant STRAIGHT proofing strip installed by means of a mounting strip.



The STRAIGHT proofing strip can be used for proofing up to up to 1.4 in (3½ cm) wide gaps.

The proofing of wooden garage doors is described in section 2. The proofing of garage doors of metal is described in section 3. There are some valuable tips and tricks in section 4.

## 1.2 Installation With or Without a Mounting Strip

The STRAIGHT proofing strip can be secured to the garage door with or without the use of a mounting strip. A mounting strip is used when an aesthetically pleasing installation is called for. This guide covers installation with a mounting strip. A guide on how to install the STRAIGHT proofing strip without the use of a mounting strip (i.e. with the use of screws and washers only) can be downloaded from [www.ro-dexit.com](http://www.ro-dexit.com).

## 1.3 Do Not Press the Proofing Strip Hard Against the Threshold and the Side Jambs

Do not press the proofing strip hard against the threshold and the side jambs. It should make featherlight contact only.



## 1.4 Bottom Weather Seals


If there is a bottom weather seal under the garage door, and it is OK, leave it on.



If it isn't OK, replace it and recalibrate the door opener if any before installing the STRAIGHT proofing strip.

## 1.5 Mounting Strips

Numerous different strips can be used as mounting strips. RodeXit recommends aluminum carpet trims of the angled flat bar type because they can cover the upper edge of the proofing strip:




Carpet trim of the angled flat bar type



Upper edge of an installed carpet trim of the angled flat bar type

The width and the gap height of an angled flat bar carpet trim are important:



This guide covers installation with the use of 1 3/8 to 2 in (35 to 51 mm) wide angled flat bar carpet trims of aluminum with predrilled holes and

- a gap height of 0.16 to 0.25 in (4 to 6 mm) (hereinafter called Low Carpet Trims) or
- a gap height of 0.3 to 0.4 in (8 to 10 mm) (hereinafter called High Carpet Trims).

Low Carpet Trims can be used for single layer installations. High Carpet Trims can be used for double layer installations:



Single layer installation with a 1 3/8 in (35 mm) wide Low Carpet Trim



Double layer installation with a 2 in (51 mm) wide High Carpet Trim

Double layer installations are used when a very high degree of protection is required – for example when the rodent pressure is very high.


Both Low Carpet Trims and High Carpet Trims are quite common and can be procured from well-assorted hardware stores.

The height specifications if any on the websites of carpet trim producers and hardware stores are unfortunately not always 100 % trustworthy. You should therefore always check the gap height when procuring carpet trims, you haven't used before.

You can download a list of recommended carpet trims from [www.rodexit.com/mounting-guides](http://www.rodexit.com/mounting-guides). The list will be periodically updated with further carpet trims.

## 1.6 Monitoring and Maintenance

All rodent proofed garage doors should at regular intervals be monitored for maintenance needs. The proofing strips should be fixed or replaced if they are seriously compromised – for example due to severe rodent attacks.



## 2 PROOFING WOODEN GARAGE DOORS

### 2.1 Tools and Materials

You will need these tools and materials:

- A. A roll of STRAIGHT proofing strip.
- B. Tin snips for trimming the proofing strip – preferably straight tin snips with long blades.
- C. A staple gun with suitable staples for temporarily attaching the proofing strip to the door.

- D. A sufficiently long Low Carpet Trim or High Carpet Trim (hereinafter called: “the mounting strip”).
- E. A hacksaw or another metal cutting device for trimming the mounting strip.
- F. A metal file for deburring the cut end of the mounting strip.
- G. Suitable flatheaded screws for example 1 inch (25 mm) long No. 10 (4.8 mm) hex head screws or pan head screws.
- H. A corresponding screw bit.
- I. A cordless screwdriver.
- J. A couple of around 2 pounds (1 kg) heavy objects for holding the mounting strip in place during the installation.
- K. Possibly: Washers by means of which you can reduce the risk of denting the mounting strip if too much force is used when screwing the mounting strip onto the garage door.
- L. Possibly: A drill bit for drilling pilot holes in the garage door.



## 2.2 Proofing the Threshold Gap

The STRAIGHT proofing strip shall be mounted on the exterior side of the garage door. It must be possible to secure screws firmly in the lowermost 2 in (5 cm) of the door.

Follow these steps:

1. If the door is equipped with side seals of the clip-on reverse angle jamb type (clipped onto the garage door tracks),
  - a. dismantle the side seals and
  - b. install ordinary stop molding side seals or brush seals as replacements after installing the proofing strip.



2. Close the garage door completely.



3. If there is an automatic opener, unplug it.



4. If there is a left side seal, tuck the free end of the roll behind it (if necessary after loosening it):



Tucked under stop molding side seal installed on the side jamb



Tucked under brush side seal installed on the door

If there isn't sufficient room behind the side seal:

- loosen it or
- dismount it and remount it after installing the proofing strip.

NB: A sectional garage door will usually move somewhat inwards when it starts opening.

5. By means of a staple attach the free end of the roll to the left side of the door:



No side seal



With stop molding side seal installed on the side jamb



With brush side seal installed on the door

If the garage door is a retractable single panel door, don't let the proofing strip extend beyond the side of the door panel. If it does, there is a risk that the proofing strip will hit the side jambs in an undesirable way when the door opens.

6. Unroll a little more of the proofing strip than you need for proofing the threshold gap:



7. Cut off a slightly oversized piece.



8. With staples placed in the uppermost 1 inch (2.5 cm) of the proofing strip attach the oversized proofing strip to the door from left to right until you are around 2 feet (60 cm) from the right side jamb.



9. Trim the proofing strip

- if the door is a sectional door or a single panel canopy door:
  - to the width of the door opening or
- if the door is a single panel retractable door:
  - to the width of the door panel.



10. If there is a right side seal, tuck the free end of the trimmed proofing strip behind the side seal.



Tucked under stop molding side seal installed on the side jamb.



Tucked under brush side seal installed on the door.

If there isn't sufficient room behind the side seal:

- loosen it or
- dismount it and remount it after installing the proofing strip.

NB: A sectional garage door will usually move somewhat inwards when it starts opening.

11. With staples attach the last around 2 feet (60 cm) of the proofing strip to the door.

## 12. Trim the mounting strip

- if the door is a sectional door:
  - to the width of the door opening minus 0.4 in (1 cm) on each side or
- if the door is a single panel door:
  - to the width of the door panel, and debur the cut end.



Trimming



Deburring

Use sturdy gloves to protect your hands.

## 13. If there are any side seals, tuck the ends of the trimmed mounting strip behind the side seals:



Tucked behind stop molding side seals installed on the side jambs



Tucked behind brush side seals installed on the door

If there isn't sufficient room behind the side seals:

- loosen them or
- dismount them and remount them after installing the proofing strip.

NB: A sectional garage door will usually move somewhat inwards when it starts opening.

14. Screw the mounting strip onto the garage door.

Use a couple of around 2 pounds (1 kg) heavy objects for holding the mounting strip in place:




Don't let the mounting strip extend below the bottom of the garage door.

Don't use too much force. You risk denting the mounting strip. You can reduce the risk if you use washers.

Use suitable screws – not necessarily the ones that come with the mounting strip if any.

It is no problem if the screws are slightly larger than the predrilled holes. The screws will automatically widen the holes when driven in.

Place a screw in each of the predrilled holes of the mounting strip (if necessary, after drilling pilot holes in the door):



15. Remember to

- retighten any loosened side seals,
- reinstall any dismantled side seals, and
- install any replacement side seals.

16. Open and close the garage door in order to secure that it operates satisfactorily.



If it doesn't, you can probably solve the problem by doing one or more of the following:

- Adjust the opening and closing power of the opener – if any. Check the owner’s manual and follow the instructions.
- Adjust the position of the side seals if any.
- If there are side seals of the stop molding type, replace them with brush seals.
- Adjust the garage door rails. Check the owner’s manual and follow the instructions.

## 2.3 Proofing the Side Gaps

### 2.3.1 Installation of the STRAIGHT Proofing Strip

The STRAIGHT proofing strip is secured to the door in much the same way as when you proof the threshold gap. Use a top-down approach.

Don’t let the mounting strips extend beyond the sides of the door, and don’t install them closer to the jambs than 0.4 in (1 cm).

Let the horizontal and vertical proofing strips adjoin in the corners. Don’t let them overlap.


The best-looking way to join the vertical and horizontal mounting strips is to install the vertical mounting strips so A) they adjoin the upper edge of the horizontal mounting strip, and B) they align with the ends of the horizontal mounting strip:



That should naturally be taken into consideration already when the horizontal mounting strip is trimmed.


If there is a brush side seal on the door, it may be used as mounting strip instead of a carpet trim:

A 2½ in (6½ cm) or more wide brush strip will cover all of the vertical proofing strip.



### 2.3.2 Single Panel Canopy Doors


The STRAIGHT proofing strip can be used for rodent proofing the lower part of the side gaps that corresponds to the exterior canopy part of the door.



Depending on the way the concrete single panel canopy door operates it may be feasible to proof the entire side gaps with STRAIGHT proofing strips without impeding the opening and closing of the garage door. However, there is a risk that the proofing strips will rub against the side jambs in an undesirable way.


### 2.3.3 Sectional Doors

Depending on the way the concrete sectional door operates it may be feasible to rodent proof the lower-most 1-2 feet (30-60 cm) of the side gaps with STRAIGHT proofing strips without impeding the opening and closing of the garage door. However, there is a risk that the proofing strips will rub against the side jambs in an undesirable way.



### 2.3.4 Single Panel Retractable Doors

Depending on the way the concrete retractable single panel door operates it may be feasible to proof the entire side gaps (as opposed to a part thereof) with STRAIGHT proofing strips without impeding the opening and closing of the garage door. However, there is a risk that the proofing strips will rub against the side jambs in an undesirable way.



### 2.3.5 Rodent Proofing Stop Molding Side Seals

If the garage door is equipped with stop molding side seals, you can use a “Garage Door Rodent Guard” kit from The Rickford Company for rodent proofing the lower part of the side seals and thereby the lower part of the side gaps:



## 3 PROOFING METAL GARAGE DOORS

### 3.1 Tools and Materials

You will need the tools and materials listed in section 2.1 except the staple gun and the staples. Instead of the staples you can use blobs of sticky power tack for temporarily attaching the proofing strip to the door:



You may also need:

- A Stanley knife for reducing the width of the proofing strip.

- A wood plank to be used as cutting board when using the Stanley knife.




### 3.2 Proofing the Threshold Gap and the Side Gaps

A garage door of metal is proofed in much the same way as a wooden door. The screws must be secured firmly in solid structural parts. The screws are usually secured in the base of the door when the threshold gap is proofed.

When the screws are placed in the base of the door it is often a good idea to use a mounting strip that is only 1 3/8 in (35 mm) or less wide. That is because a wider mounting strip often will extend below the bottom edge of the garage door.

The predrilled holes of the proofing strip must naturally be aligned with the solid part of the door where the screws are to be placed (for example in the base of the door). In order to achieve that it may be necessary to reduce the width of the proofing strip.

If the width isn't reduced, it may for example look like this:



The green dotted quadrangle marks the solid structural part of the metal garage door where it is possible to secure the screws firmly.

The red dotted quadrangle marks the excess part of the proofing strip that must be cut off in order to reduce the width of the proofing strip before installation.

This is how the example installation looks after

- a reduction of the width of the proofing strip and

- subsequent reinstallation of the proofing strip and the mounting strip:



The width of the proofing strip is easily reduced with a Stanley knife. When you place the knife between 2 of the parallel steel wires in the proofing strip, the wires will guide the knife, so you always will get a fairly straight cut. Place the proofing strip on a wood plank when you cut it. Use sturdy gloves to protect your hands.



Mount the proofing strip with the cut side hidden under the mounting strip.

It is generally a good idea to use self-drilling screws with a drill point.

## 4 TIPS & TRICKS

### 4.1 If a Very High Degree of Protection is Required

Under normal circumstances it is sufficient to install a single layer. If a particularly high degree of protection is required – for example because of a very high rodent pressure – you should install a double layer:




A double layer is installed in the same way as a single layer.

#### 4.2 How to Handle Very Uneven Thresholds

If the garage door threshold is so uneven that there will be substantial gaps under the STRAIGHT proofing strip, the threshold should be repaired before installing the proofing strip.

Though it is not the optimal solution, you can as an alternative cut the STRAIGHT proofing strip in several pieces and mount them overlapping and at an angle as exaggeratedly illustrated here:



Two pieces temporarily attached with staples overlapping and at an angle



Same finally installed with a High Mounting Strip

If you solve the problem in that way, you should use a mounting strip in the form of a High Carpet Trim – that is an angled flat bar carpet trim with a gap height of 0.3 to 0.4 in (8 to 10 mm).

The right angles come naturally when the pieces of proofing strip are placed on the ground.

Another way of dealing with uneven thresholds is to supplement the STRAIGHT proofing strip with a brush strip that conforms better to uneven surfaces:



Installed with a 1 3/8 in (35 mm) wide Low Carpet Trim and a 2 in (50 mm) wide brush strip

### 4.3 Why Are Tin Snips with Long Blades Best?

Straight tin snips with long blades are better than straight tin snips with ordinary blades first and foremost because it is a lot easier to make straight cuts with the long blades.



Furthermore, it is possible to cut the STRAIGHT proofing strip in a single clip if you have strong hands.

### 4.4 A Very Useful Homemade Tool

If you on a regular basis use RodeXit seals, it is a good idea to make a simple and inexpensive “third hand” tool that is capable of A) holding a RodeXit seal in place and at the same time B) elevating and holding a mounting strip. It is often handy to have 2 of the homemade tool.

The tool can be made from

- a 1 - 1¼ in (2½ - 3 cm) thick and around 2 pound (1 kg) heavy piece of wood (preferably of heavy wood such as oak) and
- two around 2½ in (6½ cm) long screws.

You place a screw around 1 in (2½ cm) from each end of the piece of wood and around ½ in (13 mm) from the edge. Drive in the screws around 1 in (2½ cm), so the distance between the heads of the screws and the wood is around 1½ in (4 cm). The finished tool should look somewhat like this:



This is how it works:

